



HAYWARD®

092010E RevC

GLX-FLO-RP

Replacement Flow Switch

Owner's Manual



Contents

Introduction.....	1
Installation.....	1

GLX-FLO-RP-25

**REGISTER
NOW**

to extend your
WARRANTY

see back of manual for details

Hayward Industries
400 Connell Drive, Suite 6100
Berkeley Heights, NJ 07922
Phone: (908) 355-7995
www.hayward.com

USE ONLY HAYWARD GENUINE REPLACEMENT PARTS



HAYWARD®

Introduction

Compatibility

Replacement flow switch for use on the following chlorinators:

- Aqua Rite Electronic Chlorine Generators (all models)
- Naturesoft Water Purification System (all models)
- Mineral Springs (all models)
- Aqua Trol Above Ground Pool Automation (all -HP models)
- SplashCLEAR (all models except -RJ versions)

See the reverse side for the warranty on this part.

Installation


Digital Display Units:

1. Unscrew flow switch from the plumbing tee by turning it counterclockwise until the switch is completely out of the tee.
2. Carefully bend rubber flaps if applicable and insert into the tee making sure not to damage the switch.
3. Tighten switch to make sure there are no leaks. Do not over-tighten!
4. Make sure that the arrows on the flow switch are facing in the direction of water flow.
5. Plug the flow switch into the connection on the bottom of the electronics unit.

Non-Display Units: (Using 4 conductor wire)

Follow steps 1-4 above, then:

5. Cut the connector off the 4 conductor cable and strip back the jacket.
6. Cut off the yellow and black wires on the 4 conductor cable -- they are not used.
7. Strip the green and red wires and connect to the terminal strip in the electronics unit per the wiring diagram on the inside of the door. (see below)






HAYWARD®

Non-Display Units: (Using 2 conductor wire)

Follow steps 1-4 on the previous page, then:

5. Cut the connector off the 2 conductor cable and strip back the jacket.
6. Strip the red and black wires and connect to the terminal strip in the electronics unit per the wiring diagram on the inside of the door. (see below)



90 DAY EXTENDED WARRANTY*

REGISTER WITH YOUR SMARTPHONE

— PROTECT YOUR INVESTMENT IN 2 EASY STEPS —

1. TAKE A PHOTO

Take a photo of the camera icon



2. SEND IT IN

Send it in using **one** of the methods below



SMARTPHONE

Text a photo of the camera icon to **71403**

OR



ONLINE

Visit Hayward.com/Warranty

OR



MESSENGER

Send photo to **photoregister**

*Extended warranty is in addition to applicable product warranty and is for parts only, labor not included.

Need help? Visit photoregister.com/help or text HELP to 71403.

For further information or consumer
technical support, visit our website at
www.hayward.com



HAYWARD®



Hayward is a registered trademark of Hayward Industries, Inc. © 2019 Hayward Industries, Inc.

All other trademarks not owned by Hayward are the property of their respective owners.
Hayward is not in any way affiliated with or endorsed by those third parties.

USE ONLY HAYWARD GENUINE REPLACEMENT PARTS