



EcoStar Digital Control Interface Cover Replacement

⚠ ATTENTION — Refer to EcoStar Pump Owner's Guide (IS3400VSP) for all applicable pump warning, installation, operation, and troubleshooting information. Owner's guides may also be obtained online at www.haywardpool.com.

1. Open digital control interface cover slightly.
2. Apply moderate pressure with thumb to center of cover, pulling backward gently on either side of the cover to disengage hinge and remove.



3. Align one hinge between replacement cover and bezel.



4. Again, apply moderate pressure with thumb to center of cover, pulling backward gently on either side.
5. Align second hinge between cover and bezel, and release thumb pressure to secure.